









































BACK

IFACS-052

 <p>22-18 GA BUTT CONNECTOR</p>  <p>ASN345</p>	 <p>22-18 GA RING #6 STUD</p>  <p>A52006</p>	 <p>22-18 GA RING #10 STUD</p>  <p>A52110</p>	 <p>22-18 GA SPADE #6 STUD</p>  <p>A53506</p>	 <p>12-10 GA QUICK DISCONNECT FEMALE</p>  <p>C5265</p>
 <p>16-14 GA BUTT CONNECTOR</p>  <p>BSN331</p>	 <p>16-14 GA RING #10 STUD</p>  <p>B53910</p>	 <p>16-14 GA RING 1/4 STUD</p>  <p>B52514</p>	 <p>16-14 GA RING 3/8 STUD</p>  <p>B51838</p>	 <p>16-14 GA SPADE #10 STUD</p>  <p>B52710</p>
 <p>12-10 GA BUTT CONNECTOR</p>  <p>CSN346</p>	 <p>12-10 GA RING #10 STUD</p>  <p>C52810</p>	 <p>12-10 GA RING 1/4 STUD</p>  <p>C53014</p>	 <p>12-10 GA RING 3/8 STUD</p>  <p>C54038</p>	 <p>12-10 GA SPADE #10 STUD</p>  <p>C54110</p>
 <p>22-18 GA QUICK DISCONNECT MALE</p>  <p>AA5260</p>	 <p>22-18 GA QUICK DISCONNECT FEMALE</p>  <p>AA5261</p>	 <p>16-14 GA QUICK DISCONNECT MALE</p>  <p>BB5262</p>	 <p>16-14 GA QUICK DISCONNECT FEMALE</p>  <p>BB5263</p>	 <p>12-10 GA QUICK DISCONNECT MALE</p>  <p>C5264</p>

CRIMPER



FRONT