


BACK

IFACS-113

 <p>#8-32 X 1 THUMB SCREW SHOULDER</p>  <p>8C100MTSZ</p>	 <p>#10-24 X 1 THUMB SCREW SHOULDER</p>  <p>10C100MTSZ</p>	 <p>#10-32 X 1 THUMB SCREW SHOULDER</p>  <p>10F100MTSZ</p>	 <p>1/4-20 X 1 THUMB SCREW SHOULDER</p>  <p>25C100MTSZ</p>	 <p>5/16-18 X 1 THUMB SCREW SHOULDER</p>  <p>31C100MTSZ</p>	 <p>3/8-16 X 1 THUMB SCREW SHOULDER</p>  <p>37C100MTSZ</p>
 <p>#8-32 X 1 THUMB SCREW</p>  <p>8C100MTPZ</p>	 <p>#10-24 X 1 THUMB SCREW</p>  <p>10C100MTPZ</p>	 <p>#10-32 X 1 THUMB SCREW</p>  <p>10F100MTPZ</p>	 <p>1/4-20 X 1 THUMB SCREW</p>  <p>25C100MTPZ</p>	 <p>5/16-18 X 1 THUMB SCREW</p>  <p>31C100MTPZ</p>	 <p>3/8-16 X 1 THUMB SCREW</p>  <p>37C100MTPZ</p>
<p>3/8-16</p>  <p>WING NUT</p>  <p>37CNWIFZ</p>	<p>7/16-14</p>  <p>WING NUT</p>  <p>43CNWIFZ</p>	<p>1/2-13</p>  <p>WING NUT</p>  <p>50CNWIFZ</p>			
<p>#6-32</p>  <p>WING NUT</p>  <p>6CNWIFZ</p>	<p>#8-32</p>  <p>WING NUT</p>  <p>8CNWIFZ</p>	<p>#10-24</p>  <p>WING NUT</p>  <p>10CNWIFZ</p>	<p>#10-32</p>  <p>WING NUT</p>  <p>10FNWIFZ</p>	<p>1/4-20</p>  <p>WING NUT</p>  <p>25CNWIFZ</p>	<p>5/16-18</p>  <p>WING NUT</p>  <p>31CNWIFZ</p>

FRONT