

































































BACK

 3/8 SLEEVE  60-6	 3/8 NUT  61-6	 3/8 UNION  62-6	 3/8 X 1/8 MALE ADAPTER  68-6-2	 3/8 X 1/4 MALE ADAPTER  68-6	 3/8 X 3/8 MALE ADAPTER  68-6-6	 3/8 X 1/8 MALE ELBOW  69-6-2	 3/8 X 1/4 MALE ELBOW  69-6
 1/4 X 1/4 MALE ELBOW  69-4-4	 5/16 SLEEVE  60-5	 5/16 NUT  61-5	 5/16 UNION  62-5	 5/16 X 1/8 MALE ADAPTER  68-5	 5/16 X 1/4 MALE ADAPTER  68-5-4	 5/16 X 1/8 MALE ELBOW  69-5	 5/16 X 1/4 MALE ELBOW  69-5-4
 3/16 X 1/8 MALE ADAPTER  68-3	 3/16 X 1/8 MALE ELBOW  69-3	 1/4 SLEEVE  60-4	 1/4 NUT  61-4	 1/4 UNION  62-4	 1/4 X 1/8 MALE ADAPTER  68-4	 1/4 X 1/4 MALE ADAPTER  68-4-4	 1/4 X 1/8 MALE ELBOW  69-4
 1/8 SLEEVE  60-2	 1/8 NUT  61-2	 1/8 UNION  62-2	 1/8 X 1/8 MALE ADAPTER  68-2	 1/8 X 1/8 MALE ELBOW  69-2	 3/16 SLEEVE  60-3	 3/16 NUT  61-3	 3/16 UNION  62-3

FRONT