

BACK

| | | | | | |
|---|--|--|--|---|--|
|  <p>#8-32 X 1 THUMB SCREW SHOULDER</p>  <p>8C100MTSZ</p> |  <p>#10-24 X 1 THUMB SCREW SHOULDER</p>  <p>10C100MTSZ</p> |  <p>#10-32 X 1 THUMB SCREW SHOULDER</p>  <p>10F100MTSZ</p> |  <p>1/4-20 X 1 THUMB SCREW SHOULDER</p>  <p>25C100MTSZ</p> |  <p>5/16-18 X 1 THUMB SCREW SHOULDER</p>  <p>31C100MTSZ</p> |  <p>3/8-16 X 1 THUMB SCREW SHOULDER</p>  <p>37C100MTSZ</p> |
|  <p>#8-32 X 1 THUMB SCREW</p>  <p>8C100MTPZ</p> |  <p>#10-24 X 1 THUMB SCREW</p>  <p>10C100MTPZ</p> |  <p>#10-32 X 1 THUMB SCREW</p>  <p>10F100MTPZ</p> |  <p>1/4-20 X 1 THUMB SCREW</p>  <p>25C100MTPZ</p> |  <p>5/16-18 X 1 THUMB SCREW</p>  <p>31C100MTPZ</p> |  <p>3/8-16 X 1 THUMB SCREW</p>  <p>37C100MTPZ</p> |
|  <p>3/8-16 WING NUT</p>  <p>37CNWIFZ</p> |  <p>7/16-14 WING NUT</p>  <p>43CNWIFZ</p> |  <p>1/2-13 WING NUT</p>  <p>50CNWIFZ</p> | | | |
|  <p>#6-32 WING NUT</p>  <p>6CNWIFZ</p> |  <p>#8-32 WING NUT</p>  <p>8CNWIFZ</p> |  <p>#10-24 WING NUT</p>  <p>10CNWIFZ</p> |  <p>#10-32 WING NUT</p>  <p>10FNWIFZ</p> |  <p>1/4-20 WING NUT</p>  <p>25CNWIFZ</p> |  <p>5/16-18 WING NUT</p>  <p>31CNWIFZ</p> |

FRONT