

## 61 PC BRASS HOSE BARB ASSORTMENT

BACK

IFACS-049

 <p>1/4 X 1/8 HOSE BARB ELBOW</p>  <p>1569-4-2</p>	 <p>1/4 X 1/4 HOSE BARB ELBOW</p>  <p>1569-4-4</p>	 <p>3/8 X 1/4 HOSE BARB ELBOW</p>  <p>1569-6</p>	 <p>3/8 X 3/8 HOSE BARB ELBOW</p>  <p>1569-6-6</p>	 <p>1/2 X 3/8 HOSE BARB ELBOW</p>  <p>1569-8</p>	 <p>1/4 X 1/8 FEMALE HOSE BARB ADAPTER</p>  <p>1566-4</p>
 <p>3/8 X 1/4 MALE HOSE BARB ADAPTER</p>  <p>1568-6</p>	 <p>3/8 X 3/8 MALE HOSE BARB ADAPTER</p>  <p>1568-6-6</p>	 <p>1/2 X 3/8 MALE HOSE BARB ADAPTER</p>  <p>1568-8</p>	 <p>1/2 X 1/2 MALE HOSE BARB ADAPTER</p>  <p>1568-8-8</p>	 <p>5/8 X 1/2 MALE HOSE BARB ADAPTER</p>  <p>1568-10-8</p>	 <p>3/4 X 1/2 MALE HOSE BARB ADAPTER</p>  <p>1568-12</p>
 <p>1/8 X 1/8 MALE HOSE BARB ADAPTER</p>  <p>1568-2</p>	 <p>3/16 X 1/8 MALE HOSE BARB ADAPTER</p>  <p>1568-3</p>	 <p>1/4 X 1/8 MALE HOSE BARB ADAPTER</p>  <p>1568-4</p>	 <p>1/4 X 1/4 MALE HOSE BARB ADAPTER</p>  <p>1568-4-4</p>	 <p>5/16 X 1/8 MALE HOSE BARB ADAPTER</p>  <p>1568-5</p>	 <p>5/16 X 1/4 MALE HOSE BARB ADAPTER</p>  <p>1568-5-4</p>
 <p>1/8 HOSE BARB SPLICE</p>  <p>1562-2</p>	 <p>3/16 HOSE BARB SPLICE</p>  <p>1562-3</p>	 <p>1/4 HOSE BARB SPLICE</p>  <p>1562-4</p>	 <p>5/16 HOSE BARB SPLICE</p>  <p>1562-5</p>	 <p>3/8 HOSE BARB SPLICE</p>  <p>1562-6</p>	 <p>1/2 HOSE BARB SPLICE</p>  <p>1562-8</p>

FRONT