

BACK

 3/4 & 7/8 TOOL  R72875	DRILL 1 1/16 TAP 1 1/8-12  3/4-10 KEYSERT  R73122	DRILL 1 1/16 TAP 1 1/8-12  3/4-16 KEYSERT  R74122					
 1/2 & 9/16 TOOL  R72500	DRILL 37/64 TAP 5/8-11  1/2-13 KEYSERT  R73081	DRILL 37/64 TAP 5/8-11  1/2-20 KEYSERT  R74081	DRILL 45/64 TAP 3/4-16  9/16-12 KEYSERT  R73092	DRILL 45/64 TAP 3/4-16  9/16-18 KEYSERT  R74092	 5/8 TOOL  R72625	DRILL 53/64 TAP 7/8-14  5/8-11 KEYSERT  R73102	DRILL 53/64 TAP 7/8-14  5/8-18 KEYSERT  R74102
 5/16 TOOL  R72312	DRILL LETTER X TAP 7/16-14  5/16-18 KEYSERT  R73051	DRILL LETTER X TAP 7/16-14  5/16-24 KEYSERT  R74051	 3/8 & 7/16 TOOL  R72375	DRILL 29/64 TAP 1/2-13  3/8-16 KEYSERT  R73061	DRILL 29/64 TAP 1/2-13  3/8-24 KEYSERT  R74061	DRILL 33/64 TAP 9/16-12  7/16-14 KEYSERT  R73071	DRILL 33/64 TAP 9/16-12  7/16-20 KEYSERT  R74071
 # 10 TOOL  R72190	DRILL LETTER I TAP 5/16-18  #10-24 KEYSERT  R73601	DRILL LETTER I TAP 5/16-18  #10-32 KEYSERT  R74601	 1/4 TOOL  R72250	DRILL LETTER Q TAP 3/8-16  1/4-20 KEYSERT  R73041	DRILL LETTER Q TAP 3/8-16  1/4-28 KEYSERT  R74041		

FRONT